

# SeaCom 211 operating instruction

DOC110812CJ01\_01



## Features

- |                     |                                                                                                                                                         |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Speaker/<br>headset | The SC211 is always mounted with a horn speaker or a headset or both.<br>The picture above shows an installation with hornspeaker only                  |
| Call sound          | The horn speaker will sound the alert sound whenever the station is called.<br>Many installation have external horn/flash for boosting call indication. |
| Keys                | 3 keys are preprogrammed to call fixed locations on board.<br>When in conversation any of these keys are used as push-to-talk buttons.                  |

## Making calls

- Using horn      Press one of the three call keys  
 Await the answering  
 Conduct the conversation in push-to-talk mode speaking into horn.  
 The station terminates automatically when called party terminates
- Using headset    Press one of the call keys or the push-to-talk button of the headset.  
 Await answering  
 Conduct the conversation using the push-to-talk button of headset  
 The station terminates automatically when called party terminates

## Receiving calls

- Using horn      Press one of the call keys to answer call  
 Conduct the conversation in push-to-talk mode speaking into horn.  
 The station terminates automatically when calling party terminates
- Using headset    Press the push-to-talk button of the headset  
 Conduct the conversation using the push-to-talk button of headset  
 The station terminates automatically when calling party terminates
- Talk-back        A talk back call need no hands on  
 Conduct conversation in hands-free, speaking when master station  
 is listening.  
 The station terminates automatically when talk-back master  
 terminates.

## Conducting a call

- Horn speaker    The horn speaker is used both for speaker and for microphone. Voice can  
 only flow in one direction, either the horn is speaking or it is used as  
 microphone. The direction is controlled by pressing one of the call keys  
 in a push-to-talk fashion. When pressing a key, the speaker turns into a  
 microphone, and when releasing the key, the spekaer tuns back into a  
 speaker.
- If the SC211 station is used as a talk back station, the speech direction is  
 controlled from the talk-back conference master, and no hands on is  
 needed on the SC211 station for alternating the speech direction.
- Headset         The headset can have a push-to-talk-button which is used to alternate  
 speech direction of the headset.  
 If set up the headset can be used in full duplex .

## Headset connector

A headset can be connected using a water tight connector set. The connector allows for removing the headset when not in use. The connector is **NOT** water tight when left open, so it is important to mount the cover properly when the headset is removed, in order to leave it tight and closed for mositure. Failure to do so will reduce lifetime.